

Pollution Prevention Program

Oil-CAT Quick Start Guide



-
- Step 1.** Confirm that vehicle fuel tank contains #2 diesel fuel or JP-8 only.
 - Step 2.** Confirm that vehicle fuel tank has sufficient room to hold volume of oil from crankcase, and is at least $\frac{3}{4}$ full.
 - For Hummies remove screen in fill spout.
 - For 2 $\frac{1}{2}$ ton and larger vehicles fuel level should be 1" above the bottom of the fuel fill screen.
 - Step 3.** Insert double red/green "fuel hose" into the fuel tank of the vehicle.
 - Step 4.** Connect red "oil hose" from Oil-CAT to red Oil Drain Tote.
 - Step 5.** Place Oil Drain Tote under vehicle drain plug, pull plug and drain crankcase oil into red Oil Drain Tote.
 - Step 6.** When all oil is drained from crankcase, replace drain plug and refill with new oil and filter as per established maintenance procedures.
 - Step 7.** Rotate $\frac{1}{4}$ turn valves on red Oil Drain Tote and on red hose to the open position.
 - Step. 8** Start Oil-CAT by turning timer past the 10-minute mark. Actual processing time is equal to 1 minute for every quart of waste oil. If additional time is needed, simply turn timer past 10-minute mark and then set to actual time desired.
 - Step. 9** When all oil is processed, Oil-CAT will automatically turn off when the timer hits zero. The unit can also be manually turned off by setting timer to "0". When finished coil red/green and red hose onto the hose rack taking care not to drip any fluids.